

# Wireless Occupancy Sensor Dimming Wall Controller

#### Overview

- Passive Infrared (PIR)
   Occupancy Sensor
- Bluetooth® SIG mesh
- Manual on/off (wireless)
- Conforms with DLC NLC5 Cybersecurity Standards
- Dim up/down (wireless)
- LED Status Indicator Light
- Mounts in any Standard Wall Box
- Color: White









## **Applications**

mwConnect's Wireless Occupancy Sensor Dimming Wall Controller (PSC-DM-I-WS-100-BLE-SR) provides automatic, occupancy-based lighting control for a variety of indoor applications. It can be mounted in any standard single-gang wall box.

PIR detection is best suited for areas with clear line of sight. Typical applications include classrooms, copy rooms, private offices, conference rooms, and private restrooms.

## **Operation**

**TruBlu<sup>™</sup> Mesh Controls:** Qualified by Bluetooth SIG for its Bluetooth Mesh 1.0.1 specification, the wall controller connects to a Bluetooth mesh network and is accessed via the TruBlu web portal or mobile app for initial design, setup and scheduling, as well as subsequent parameter adjustments.

End users can then program length of time delays, fade time, and other settings using these design and commissioning tools.

The PSC-DM-WS-400-BLE-SR controls all of the lights in a specific zone. The unit also functions as a dimmer to override the pre-configured occupancy sensor settings

See the TruBlu<sup>TM</sup> Commissioning User Manual for more information.

## Summary

Sensor Type:

PIR Occupancy/Vacancy Sensor Dimmer

Input Voltage | Power Consumption: 120-277 VAC, 50/60Hz I Max 1.5W

Mounting: Standard wall box

Max Range: 40 ft @ 4ft mounting height (12.2m @ 1.2m mounting height)

Max Bluetooth Range<sup>1</sup>: 30ft (9.14m)

Operating Temperature: 0° to 55°C

Storage Temperature: -10° to 60°C

Relative Humidity: 90-95% non-condensing at 30°C

Color: White

Warranty: 5 years

Note:


1. Bluetooth Range is highly dependent on the integration of fixtures, surrounding environment and conditions. It is recommended to conduct testing for range accuracy.

Project	
Location/Type	






# **Physical Dimensions**




# **Wiring Diagram**




Drawings are Not to Scale


## **Examples**



### **Detection Area**



### **Wireless Manual Control**



#### Button 1 for On/Off:

Short press - AUTO/ON

Second short press - OFF

Auto = Resume automatic control; turns on the automatic settings for luminaires (defined by the settings profile).

#### For dimming:

Raise Rocker

Lower Rocker

#### Factory reset:

Hold both Button 1 and Lower Toggle for 10 sec. The device returns to an un-provisioned state.

## **How to Order**

Model No.	Description	Input Voltage
PSC-DM-I-WS-100-BLE-SR	Wireless PIR Occupancy Sensor Dimming Wall Controller, TruBlu Bluetooth Mesh, Silvair Technology partner (decorator plate not included)	120-277 VAC, 60Hz

Design and specifications are subject to change without notice.

